



Scientific Solutions For Fitness™

Product Specifications

SCIFIT REX™ Total Body Recumbent Elliptical

Features	<ul style="list-style-type: none">• Super smooth exercise movement.• Total body exercise, the legs move in a natural orbital motion and the arms in a smooth arc.• Optimized kinetic energy for added ease of use.• Bi-directional resistance helps create balance between reciprocal muscle groups.• Low profile seat back for increased core recruitment.• Features Tele-Rail® system to create a silky smooth slowing and transition at each end of the range.• Dual position hand grips.• Fit-Key™ technology, optional.• Heart Rate compatible with most wireless technology.
Performance	<ul style="list-style-type: none">• Resistance system-3 phase combination generator and eddy current brake with resistance output of 5 to 2000 watts.• Computer adjustable in .1 increments with 200 levels of resistance.• Starting wattage of 7 with low minimum rpm to begin.
Programs	<ul style="list-style-type: none">• Manual - One Button Quick Start.• Heart Rate - Machine adjusts workload to maintain target heart rate.• Constant Work - With wattage as a baseline, machine maintains constant workload independent of pedal speed.• Iso-Strength - for strength training.• Random - Infinite number of program profiles.• Hill Profiles - 7 hill programs with over 20 levels of intensity.
Feedback	Heart rate, time, rpm, calories, distance, level, watts, METS
Dimensions	<ul style="list-style-type: none">• Height 55"• Length 73"• Width 28"• Weight 299 lbs.• User capacity 450 lbs.
Color	Frame - Silver powder coated Covers - Metallic Gray with UV protection
Power	Self-generating with auto recharge battery back up. Low voltage AC adaptor, optional.
Warranty	3 years parts, 1 year labor
Order Code	REX7000

Made in USA