



**Scientific Solutions For Fitness™**

## **Product Specifications**

### **SCIFIT SXT7000e<sup>2</sup> Easy Entry Total Body Elliptical**

<b>Features</b>	<ul style="list-style-type: none"><li>• Easy Entry package includes sturdy step and side handrails for safe and effortless entry. Perfect for those with flexibility or balance issues.</li><li>• All body exercise, incorporating upper body linear movement.</li><li>• Patented Bio-Flex™ articulating foot plate system.</li><li>• Bi-directional (forward/backward) resistance.</li><li>• Features Tele-Rail® telescoping rail system and requires minimal floor space.</li><li>• Vertical and horizontal rails with front crossbar.</li><li>• 15" x 7" rubber footplates with front and side safety edges.</li><li>• Elliptical has low center of gravity for user safety and stability.</li><li>• Fit-Key™ technology, optional.</li><li>• Multiple position rotational level system at four points.</li><li>• Heart Rate compatible with most wireless technology, and contact heart rate.</li></ul>
<b>Performance</b>	<ul style="list-style-type: none"><li>• Resistance system-3 phase combination generator and eddy current brake with resistance output of 5 to 2000 watts.</li><li>• Computer adjustable in .1 increments with 200 levels of resistance.</li><li>• Starting wattage of 5 with no minimum pedal speed to begin.</li></ul>
<b>Programs</b>	<ul style="list-style-type: none"><li>• Manual - One Button Quick Start.</li><li>• Heart Rate - Machine adjusts workload to maintain target heart rate.</li><li>• Constant Work - With wattage as a baseline, machine maintains constant workload independent of pedal speed.</li><li>• Iso-Strength - for strength training.</li><li>• Random - Infinite number of program profiles.</li><li>• Hill Profiles - 7 hill programs with over 20 levels of intensity.</li></ul>
<b>Feedback</b>	Heart rate, time, rpm, calories, distance, level, watts, METS
<b>Dimensions</b>	<ul style="list-style-type: none"><li>• Height 63"</li><li>• Length 75"</li><li>• Width 30"</li><li>• Weight 336 lbs.</li><li>• User capacity 425 lbs.</li></ul>
<b>Color</b>	Frame - Silver powder coated Covers - Metallic Gray with UV Protection
<b>Power</b>	Self-generating with auto recharge battery back up. Low voltage AC adaptor, optional.
<b>Warranty</b>	3 years parts, 1 year labor
<b>Order Code</b>	SXT7000E

**Made in USA**