

SCIFIT

ISO7000R Recumbent Bike

Scientific Solutions

- True adjustable step-through design with only a 3" step over height and expandable step through space at a full 23".
- Comfortable, oversized seat offers a solid foundation that eliminates rocking and instability with a user weight capacity of up to 500 lbs and additional support handlebars.
- Adjustable pedal crank option provides three adjustments (5", 6" & 7"). This allows the user more versatility to adjust their range of motion.
- Resistance system - 3 phase combination generator and eddy current brake with the largest wattage range in the industry, starting at 6 watts.
- 1-20 levels adjustable in .1 increments providing 200 levels of resistance.
- Iso-strength, coupled with bi-directional resistance allows the user to perform a leg press movement going forward and gluteus and hamstring exercise in reverse.
- Bi-directional resistance - the user can exercise in forward and reverse motion.
- Contact heart rate located on handle bars around console.
- Heart Rate compatible with most wireless technology.

Intelli-Fit[®] Features and Programs

- 7" LCD display with user friendly interface using tactile keypad, color coded with audible beep.
- Programs: One button Quick Start, Manual, Hill Profiles, Random Profiles, Heart Rate, Iso-Strength, Constant Work, Heart-Fit Test, Heart-Fit Training (4 levels with 3 programs at each level), Power-Fit Test, Power-Fit Training (4 levels with 3 programs at each level), Stress Test and Fit-Quik[™].
- Administrative mode: includes 6 user defined languages, metric or US units of measure and other custom settings.
- Built-in twin Fans: 3 levels of intensity at low, medium and high.
- Power Burst - 8 second burst of Iso-Strength. Available on all programs except: Heart-Fit Test/Training, Power-Fit Test/Training, Heart Rate, Iso-Strength and Stress Test.
- Automatic cool down after each exercise is completed.
- Download results to USB flash drive. Simply plug your USB key in the Fit-Key slot and your work-out will be copied in a text file for saving and printing.
- Display Feedback: Heart rate, time, RPM, calories, distance/miles, level, watts and MET's with two change view screens
- CSAFE port and 8-volt DC power port for TV or other controllers.
- USB charger for phones, mp3 players and other electronic devices.



www.SCIFIT.com
800.278.3933

Optional Accessories



AC Adaptor



USB Fit-Keys



Heart Rate Chest Strap



Low Support Boots



Sports Performance
Pedal



Adjustable Pedal
Cranks

Entertainment options
also available.

Technical Specifications

- Overall Dimensions: 58"L x 24" W x 53" H
- Weight of unit: 221 lbs pre packaged
- Shipping Dimensions and weight:
68" x 32" x 65" 266 lbs (Skid only)
68 5/8" x 32 1/2" x 67 9/16" 301 lbs Boxed
- Maximum user weight: 500 lbs
- Self Generating with auto recharge battery backup.

Color

Frame: Silver Powder Coated
Covers: Metallic Gray with UV Protection

Warranty

3 year parts, 1 year labor. Exceptions: 1 Year warranty on pedals and seat. Wear items (rubber hand grips and pedal straps) are excluded from warranty.

fit-Key[®]
Compatible

Order Code

ISO7010R-INT